WEREK-FB ST26 PST03-OW G



ASSEMBLY AND ADJUSTMENT INSTRUCTIONS

Before beginning the assembly, check to see that all parts are enclosed.

PART LIST

GBW065

- 1 base 5 plastic feet
- 1 gas lift
- 1 back rest
- 1 foot base with screw
- 1 seat
- 1 handwheel A

ASSEMBLY

- 1. Insert plastic feet into base.
- 2. Insert the gas lift into base.
- 3. Slide the foot base over the gas lift and fix the foot base with screw R.
- 4. Firmly locate the tapered end of the gas lift into locating hole in a seat.
- 5. Insert back rest into seat hole and tighten handwheel A.

ADJUSTMENT

- •The Seat hight adjustment lever C.
- Gas lift allows the adjustment of the seat hight.
- •The foot base hight adjustment screw R.

By releasing screw **R** the foot base can be moved up and down.

Place the foot base at desired position and retighten screw R.

•The back depth adjustment - handwheel A.

By releasing handwheel **A** the back can be moved forward and back. Place the back at desired depth and retighten handwheel **A**.

MAINTENANCE

Inspection Inspect chair at least every six months, to make sure all knobs, bolts and screws are tight.

Upholstery Wipe with damp cloth, moistened in a mild detergent solution. For unusual stains use commercial vinyl cleaner, following manufacturer's instructions.

Fabric upholstery Whisk or vacuum regularly. For unusual stains use commercial nylon cleaner, following manufacturer's instructions.

Other surfaces Wipe with a soft cloth, moistened in

a mild detergent solution. Dry and buff lightly with a dry cloth.

Attention! Exchange and installattion of gas-lifts should only be carried out by trained specialists.